


The speed of automatic slewing can be chosen between “high speed” and “middle speed”. If the **Middle** is selected, the slewing speed is reduced to half of the maximum speed. The motor noise at the GO TO slewing will be alleviated accordingly. It does not link to the maximum speed in the SCOPE MODE.

*It reduces the maximum GO TO speed only and does not link with any motion using the directional keys.



Press **Menu** to display the System Menu. Move the cursor to **GO TO speed** with the **↑** · **↓** keys and press **Select** to enter.

Choose **Middle** with the **↑** · **↓** keys. The default setting is **High**. Choose **OK** and press **Select** to enter.

*Save the setting in order for the current settings to apply the next time the STAR BOOK is used.

End.